

ZCL-ZB6 TECHNICAL DOCUMENTATION

FEATURES

- 6 outputs for 12 or 24 V motorised grilles*
- Zoning module allowing the control of up to 12 zones and up to 2 zone groups
- · Manual control through buttons and status indicator LED
- 230 V supply required for feeding of the 4 outputs
- Total data saving on power failure
- Integrated KNX BCU (TP1-256)
- Dimensions 67 x 90 x 79 mm (4.5 DIN units)
- DIN rail mounting according to IEC 60715 TH35, with fixing clamp
- CE, UKCA directives compliant (marks on the right side)

^{*} Before connecting the device to the facility, it must be assured that the switch position agrees with the grille's voltage.




Figure 1: ZoningBOX 6

1. 230 V input	Power supply LED	Grille control button	Grille status LED	Grille outputs
6. 12/24 V switch*	7. Programming/Test button	8. Programming/Test LED	KNX connector	Fixing clamp

Programming/Test button: short press to set programming mode. If this button is held while plugging the device into the KNX bus, it enters the safe mode. If this button is held for more than 3 seconds, the device enters the test mode.

Programming/Test LED: programming mode indicator (red). When the device enters the safe mode, it blinks (red) every half second. The manual mode is indicated by the green color. During the start-up (reset or after KNX bus failure) and if the device is not in safe mode, it emits a red flash.

GENERAL S	GENERAL SPECIFICATIONS					
CONCEPT			DESCRIPTION	DESCRIPTION		
Type of devic	Type of device		Electric operation control device			
	Voltage (typical)		29 VDC SELV			
	Voltage range		21-31 VDC			
KNIV augaby	Massinassina	Voltage	mA	mW		
KNX supply	Maximum consumption	29 VDC (typical)	6	174		
	'	24 VDC ¹	10	240		
	Connection type		Typical TP1 bus connector for 0.8 mm Ø rigid cable			
External power	er supply		230 VAC 50/60 Hz			
Operation ten	nperature		-5 +45 °C	-5 +45 °C		
Storage temp	erature		-20 +55 °C	-20 +55 °C		
Operation hu	midity		5 95%	5 95%		
Storage humi	dity		5 95%	5 95%		
Complementa	ary characteristic	cs	Class B	Class B		
Protection cla	Protection class		II			
Operation typ			Continuous operation	Continuous operation		
Device action	Device action type		Type 1			
Electrical stre			Long			
Degree of pro	tection		IP20, clean environment			
Installation		Independent device to be mounted inside electrical panels with DIN rail (IEC 60715)				
Minimum clea	Minimum clearances		Not required			
Response on	Response on KNX bus failure		Data saving according to parameterization			
Response on	KNX bus restar	t	Data recovery according to parameterization			
Operation indicator		Programming LED indicates programming mode (red) and test mode (green). Power indicator LED (green) represents correct feeding. Each output LED indicates its status (fixed = open grille/dumper; off = closed grilled/dumper; flashing = error, see Fig. 2)				
Weight			201 g			
PCB CTI inde	X		175 V			
Housing mate	erial		PC FR V0 halogen free			

¹ Maximum consumption in the worst-case scenario (KNX Fan-In model).

OUTPUTS SPECIFICATIONS AND CONNECTIONS					
CONCEPT		DESCRIPTION			
Number of outputs		6			
Output type / Voltage		Solid state switching device / 12 or 24 VDC (selected by switch)			
Maximum values	Quantity of grilles ²	2			
per output	Current (RMS)	750 mA			
Short-circuit protection		YES			
Overload protection		YES			
Connection method		Screw terminal block (0.5 Nm max.)			
Cable cross-section		0.5-2.5 mm ² (IEC) / 26-12 AWG (UL)			

²This value could be more restrictive depending on the current consumed by the grille.

EXTERNAL POWER SUPPLY SPECIFICATIONS AND CONNECTIONS				
CONCEPT		DESCRIPTION		
Power supply protection fuse	Voltage	250 V		
	Current	4 A		
	Response type	F (Fast acting)		
Connection method		Screw terminal block (0.5 Nm max.)		
Cable cross-section		1.5-4 mm ² (IEC) / 26-10 AWG (UL)		







Figure 2: Error notification through grille status LED

WIRING DIAGRAMS











Further information www.zennio.com







Notes:


230 V_{AC} 50/60 Hz

- The simultaneous connection of a grille to several outputs nor the connection of 12 VDC and 24 VDC grilles at the same time is not allowed.
- In case of connecting two grilles to an output, those must have similar consumption characteristics.
- The polarity of the connection must be checked. This can be done, under the Test On mode, through the grille control buttons: the first press should imply an attempt to open the grille, while the second press should cause an attempt to close it. Once the device is parameterized, switched-on LEDs should correspond to open grilles.
- After connecting a grille, a synchronisation must be provoked (for example, disconnecting and connecting the KNX bus).
- Compatibility of grilles must be checked following the next steps for a complete verification:
 - The grille must be connected to an enabled output, without other grilles in that output, (Please be careful to ensure the polarity is respected).
 - The device must be fed with auxiliary power and then connected to the KNX bus.
 - The grilles connected to outputs try a sequential opening movement. In positional mode, a maximum time of 25.5 s to complete the opening movement is allowed. In open/close mode, the maximum time is 3.5 s to complete the opening
 - Next, the grilles connected to outputs try a sequential closing movement. If the grille does not complete the closing movement, it is not suitable for ZoningBOX.



SAFETY INSTRUCTIONS AND ADDITIONAL NOTES

- Installation should only be performed by qualified professionals according to the laws and regulations applicable in each country.
- Do not connect the mains voltage nor any other external voltage to any point of the KNX bus; it would represent a risk for the entire KNX system. The facility must have enough insulation between the mains (or auxiliary) voltage and the KNX bus or the wires of other accessories, in case of being installed.
- The facility must be equipped with a device that ensures the omnipolar sectioning. Installation of a 10 A mini-circuit-breaker is recommended. To prevent accidents, it must remain open in case of manipulation of the device.
- The device has a short-circuit protection fuse that, in case of activation, should only be rearmed or replaced by the Zennio technical service.



- Once the device is installed (in the panel or box), it must not be accessible from outside.
- Keep the device away from water (condensation over the device included) and do not cover it with clothes, paper or any other material while in use. The WEEE logo means that this device contains electronic parts and it must be properly disposed of by following the instructions at

